

# NOTICE D'INSTALLATION PLAFOND DE DOUCHE ENCASTRABLE



01

### Open ceiling and drill holes

- Ceiling opening with dimension 20mm smaller than the shower head.
- Drill 4 holes for fixing 4 x M6 expansion screws at the ceiling.



02

### Installation expansion screws and suspended ring

- To fix the expansion screws and suspended ring firmly into the ceiling.



03

### Installation of long screws

- Installation of long screws
- Install long screws and cut the screws for adjustment of the suitable length.



04

### Installation of screws and spring

Installation procedures:

1. Spring washer
2. M6 screws
3. Spring (need to cut the screws and spring as well)



05

### Installation and adjustment of short tubes

- End of long screws to be fixed with 4 short tubes with adjustment.



06

### Installation of shower head and decorative front cover

- Install shower head and decorative front cover
- Adjust the level of shower head to the ceiling
- Use hexagon wrench to fix firmly decorative front cover



07

Installation completed